



Spigot Maintenance



IMPORTANT: *Be sure to follow the Maintenance instructions as outlined in the Installation and Operation Manual.*


In order to prevent a dangerous build-up of grease, soot or creosote that could potentially start a flue fire, the spigot(s) of the oven should be cleaned at least weekly (7 days) or daily for those ovens fitted with a char grill. The following images show how and where to clean the oven exhaust spigot(s) which is located directly above the door of the oven. Place a sheet of newspaper or a container below the spigot to catch any debris when cleaning.

NOTE: Only clean the oven spigot when the oven is cool – normally before the oven is turned on - before the beginning of service.

Be sure to clean the entire spigot thoroughly, all the way to the top and sides of the spigot adapter. (*Shaded area*)

Oven Facade

Spigot cleaning brush
(*Nylon, Steel or Brass*)



Oven Exhaust Spigot(s)

